



QCHBC-NI Amplified ADAPTER FOR PARROT (replaces QCHBB-NI)

You should be aware that the enclosed adapter is provided as-is. Cars can vary in terms of wiring. You are responsible for verifying your own wiring and the suitability of this harness adapter to your particular vehicle. Professional installation is therefore always suggested. Our maximum liability is limited to the original purchase price of the adapter.

***** IMPORTANT *****
 Parrot Asteroid Mini & Tablet Kits
 Use Double-ISO Pigtail Labeled
 For Parrot CK3000 and CK3100
 ***** ONLY *****



7388581011701



- 1) Plug the 24 pin black connector of our long QCNI-1MK cable in the left side of the QCHBC box. Then select a short pigtail. For the Parrot CK3000/CK3100/Asteroid Mini & Tablet, use the pigtail with the side by side ISO plugs and use it in conjunction with the supplied Parrot harness. Follow steps 2 and 4 below carefully. For the Parrot 3200/3400/MK/MKi kits, use the flat 24 pin pigtail directly into the blue Parrot brain and don't use the supplied Parrot harness. You will skip steps 2 and 4.
- 2) Your Parrot kit comes with a yellow mute wire which **MUST BE CONNECTED**. Parrot provides 3 possible receptacles for this lead marked as Mute IN 1, Mute IN 2 and Mute IN 3. **Plug the Parrot yellow mute wire with the bullet connector into the receptacle labeled "Mute In 2" ONLY. Push the bullet in firmly.** The "Mute In 1" and "Mute in 3" receptacles will not be used. You will also not be using the thin brown and green line out wires provided on the 3100 Parrot model. Simply bundle up these wires and protect them from shorts or damage.
- 3) Installing the QCHBC- NI requires unplugging two connectors from the back of your radio. This may cause a loss of your radio presets. Please write down all your presets before beginning installation so that you can reprogram them after installation.
- 4) Insert the two ISO connectors (actually one big connector that has two connectors joined on the pigtail) from the QCHBC into two matching ISO connectors on the Parrot harness. **You will notice that these two connectors can only be inserted into their proper receptacles due to their side insertion key mechanism. Two other ISO connectors from the Parrot kit go UNCONNECTED.**
- 5) Unplug the two connectors from the back of the radio or NAV unit at this time. Plug our matching connectors in their place. Push firmly and whittle a bit to get it to snap in fully. Now plug the connectors you removed from the radio into our mating connectors. Essentially you are just daisy chaining our harness in-line. Be gentle with our connectors and make sure they plug in fully. If they don't, check for bent pins.
- 6) Make sure the QCHBC Mode Switch is in MODE 1. Use a **very small flat-blade screwdriver** to adjust the Parrot levels on the side of the QCHBC-NI. Ideally, you should adjust this Cell/Music Bluetooth Audio level for both Left and Right channels so that you have maximum range when adjusting the volume with the Parrot knob. Remember, in order to set the level in the Parrot menus, you push the black knob "in" to retain the settings.
- 7) Verify that the Power LED is only on when your car is on and that the Mute LED lights during a call or during Bluetooth audio streaming.

Note: The 2 supplied female RCA phono plugs on the main harness are not used with the Parrot CK models. They can optionally be used with the MKi Parrot models if an Auxiliary Output is desired. If you use the RCA phono plugs, you must switch off the "mute on music streaming" setting in the Parrot MKi kit menu and reboot the Parrot.

Call 1-888-8-CARKIT for alternate install instructions for non-Parrot brand kits.